


3 BURNER ELECTRIC STOVE WITH OVEN **MODELS: 3142, 3342**




3 BURNER ELECTRIC STOVE WITH OVEN • MODEL: 3342, 3142

PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1.	72320	Cutting Board, 3342	35.	72234	Shield, Element
2.	72291	Lit Cover, Rear, 3342	36.	72561	Element, Bake, 120V
	72292	Lit Cover, Front, 3342		72562	Element, Bake, 240V
	80140	Lit Cover Assy., 3342	38.	72560	Socket, Oven Light
3.	72401	Element, Top, Front, 1100W, 120V		72335	Light Bulb, Oven, 120V
	72400	Element, Top, Rear, 850W, 120V		72336	Light Bulb, Oven, 240V
	72403	Element, Top, Front, 1100W, 240V	40.	72267	Trim, Lower, 3342
	72402	Element, Top, Rear, 850W, 240V		80175	Trim, Lower, 3142
4.	80155	Bowl, Element, with Clips	41.	73044	Fan, Broil
5.	72251	Main Top, SS		73045	Insert, Broiler Pan
	72256	Main Top, Porc.	42.	73432	Gasket, Oven Top
6.	72266	See Rail		73433	Gasket, Oven Sides
7.	72317	Cover, Electric		80001	Oven Can
8.	72319	Insulator, Electric Cover	43.	72227	Rotator, Filler, 3142
9.	72525	Switch, On-Off, Selector		72222	Filler, Angle, 3342
	72527	Switch, On-Off		72715B	Insulation, Oven Can
10.	72520	Switch, Infinite, 120V	45.	72296	Shield, Radiation
	72521	Switch, Infinite, 240V	46.	80145	Bottom, Ext.
11.	72522	Thermostat	48.	72409	Race Way
12.	72404	Connector Block	49.	72347	Pin, Gimbals
13.	72523	Indicator Light, 120V	50.	80045	Panel, Side, LH, 3142
	72524	Indicator Light, 240V		80046	Panel, Side, RH, 3142
14.	72576	Face Nut		80040	Panel, Side, LH, 3342
15.	72615	Handle, Switch		80041	Panel, Side RH, 3342
16.	73594	Knob		72715C	Insulation, Back
17.	72294	Trim, Control Panel	52.	72279	Panel, Back
18.	72473	Face Plate, with Rotis.	54.	72487	Bracket, Mounting, Rotis. Motor
	72476	Face Plate without Rotis.	56.	72223	Burner Box
	73218	Tray, Component	57.	72300	Grommet, 1/2"
19.	72330	Deflector	58.	72315	Drip Pan
20.	72565	Element, Broil, 120V	59.	72318	Plate, Inspection
21.	72566	Element, Broil, 240V	60.	72518	Terminal Block
22.	72329	Rack, Deflector	61.	72519	Switch, Interlock
24.	72325	Rack, Oven	62.	80015	Panel, Upper Back, 3342
25.	80303	Frame, Door	63.	80016	Panel, Upper Back, 3142
26.	73865	Glass, Oven Door, Black	64.	72307	Plug, 1-1/8"
27.	74099	Handle, Door	65.	72596	Shoulder Bolt
28.	72225	Shield, Inner Door			
29.	72715A	Insulation, Door			
30.	72196	Glass, Window, Door, Bk Glass			
31.	72226	Door Liner			
32.	80264	Hinge Assy., Door, LH			
	80265	Hinge Assy., Door, RH			
33.	72454	Arm, Spring			
34.	72216	Spring, Door			


DOOR ASSEMBLY

80011 Door Assy. Black Glass
(Items: 25, 26, 27, 28, 29, 30, 31, 32)




**3 BURNER STOVE
WITH OVEN #3142**

GIMBAL INSTALLATION



2 BURNER ELECTRIC STOVE WITH OVEN MODELS 2142, 2342



2 BURNER ELECTRIC STOVE WITH OVEN • MODEL: 2342, 2142

PARTS LIST


ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1.	72266	See Rail	33.	73432	Gasket, Oven Top
2.	72317	Cover, Electric		73433	Gasket, Oven Sides
3.	72319	Insulator, Electric Cover	34.	80002	Oven Can
4.	80047	Panel, Side, LH, 2142	35.	72295	Shield, Radiation
5.	72525	Switch, On-Off	36.	80170	Bottom, Ext.
6.	72520	Switch, Infinite, 120V	37.	72490	Race Way
	72521	Switch, Infinite, 240V	38.	72227	Retainer, Filler, 2142
7.	80042	Panel, Side, LH 2342		72222	Filter, Angle, 2342
8.	72210	Tray, Component	39.	72715B	Insulation, Oven Can
9.	72483	Face Plate	40.	80043	Panel, Side, RH, 2342
10.	72294	Trim, Control Panel	41.	80048	Panel, Side, RH, 2142
11.	72815	Handle, Switch	42.	72347	Pin, Gimbal
12.	72575	Face Nut	43.	72523	Indicator Light, 120V
13.	73594	Knob		72524	Indicator Light, 240V
14.	72331	Deflector	44.	72715C	Insulation, Back
15.	72567	Element, Broil, 120V	45.	72217	Burner Box
	72568	Element, Broil, 240V	46.	72279	Panel, Back
16.	72329	Rack, Deflector	47.	72515	Connector, Elbow, Conduit
17.	72326	Rack, Oven	48.	72586	Shoulder Bolt
18.	80303	Frame, Door	49.	72517	Conduit
19.	73885	Glass, Oven Door, Black	50.	72380	Grommet, 1/2"
20.	74099	Handle, Door	51.	72522	Thermostat
21.	72225	Shield, Inner Door	52.	72318	Plate, Inspection
22.	72715A	Insulation, Door	53.	72404	Connector Block
23.	70101	Glass, Window, Door	54.	72314	Drip Tray
24.	72226	Door Liner	55.	72518	Terminal Block
25.	80264	Hinge Assy., Door, LH	56.	80018	Panel, Upper Back, 2142
	80265	Hinge Assy., Door, RH	57.	80015	Panel, Upper Back, 2342
26.	72454	Arm, Spring	58.	72257	Main Top, SS
27.	72215	Spring, Door		72267	Main Top Parc.
28.	72234	Shield, Element	59.	72307	Plug, 1-1/8"
29.	72563	Element, Bake, 120V	60.	80155	Bowl, Element
	72564	Element, Bake, 240V	61.	72401	Element, Top, 1100W, 120V
30.	72267	Trim, Lower, 2342		72403	Element, Top, 1100W, 240V
31.	80175	Trim, Lower, 2142	62.	72519	Switch, Interlock
	73044	Pan, Broil	63.	73640	Lift Cover
	73045	Insert, Broiler Pan			
32.	72569	Socket, Oven Light			
	72335	Light Bulb, Oven, 120V			
	72336	Light Bulb, Oven, 240V			

DOOR ASSEMBLY


80011

(Items: 18, 19, 20, 21, 22, 23, 24, 25)


GIMBAL INSTALLATION



**2 BURNER STOVE
WITH OVEN #2142**



3 BURNER ELECTRIC STOVE WITHOUT OVEN • MODEL: 3542 BUILT-IN



PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1.	72320	Cutting Board	14.	73584	Knob
2.	72291	Lift Cover, Rear	15.	72499	Race Wire
	72292	Lift Cover, Front	16.	72269	Trim, Bottom
	80140	Lift Cover Assy.	17.	72523	Indicator Light, 120V
3.	72401	Element, Top, Front, 1100W, 120V		72524	Indicator Light, 240V
	72400	Element, Top, Rear, 550W, 120V	18.	72209	Bottom, Ext.
	72403	Element, Top, Front, 1100W, 240V	19.	80039	Panel, Side, RH
	72402	Element, Top, Rear, 550W, 240V	20.	72404	Connector Block
4.	80155	Bowl, Element	21.	72316	Drip Pan
5.	72251	Main Top, SS	22.	72223	Burner Box
	72256	Main Top, Porc.	23.	72300	Grommet 1/2"
6.	72286	Sea Rail	24.	72318	Plate, Inspection
7.	72317	Cover, Electric	25.	80015	Panel, Upper Back
8.	72319	Insulator, Electric Cover	26.	72281	Panel, Back
9.	80038	Panel, Side, LT	27.	72518	Terminal Block
10.	72520	Switch, Infinite, 120V	28.	72519	Switch, Interlock
	72521	Switch, Infinite, 240V	29.	72517	Conduit
11.	72218	Tray, Component	30.	72516	Connector, Conduit, Elbow
12.	72484	Face Plate	31.	72307	Plug, 1-1/8"
13.	72294	Trim, Control Panel	32.	72596	Shoulder Bolt